


① **Feature**

- ULTRA COMPACT SIZE
- 10ALERTS, SILENT (VIBRATION), BEEP
- DISPLAY TIME, DATE AND DAY OF THE WEEK
- DISPLAY NUMBERS OF UNREAD MESSAGES
- 16 MESSAGE MEMORY
- LOCK UP TO 10MESSAGES
- DETETE INDIVIDUAL OR ERASE ALL MESSAGES
- MSSAGE TIME STAMPING
- DUPLICATE MESSAGE INDICATOR
- 3 ALARM SETTING
- LOW BATTERY INDICATOR
- SERVICE AREA INDICATOR
- BACKLIGHT


② **OUTLOOKING**



**PAGER SYMBOLS**

- ☐ UNMBERS OF MESSAGES STORED
- ☑ UNREAD MESSAGE INDICATOR
- ☐ REPEAT MESSAGE INDICATOR
- ☐ LOW BATTERY INDICATOR
- ▽ SERVICE AREA INDICATOR
- 🔒 LOCKED MESSAGE
- 🕒 ALARM CLOCK
- 🕒 AUTO ON/OFF
- 🔊 STANDARD BEEP
- 🔊 VIBRATOR

③ **STAND-BY MODE**



STANDBY MODE IS THE HOME SCREEN OF THE PAGER. IT DISPLAYS THE TIME DATE AND DAY OF THE WEEK

**SET ALERT**

FROM STAND-BY MODE, RPRESS FUNCTION KEY THE SCREEN WILL THEN DISPLAY AS BELOW




PRESS SHIFT KEY TO ENTER SET ALERT MODE, PRESS FUNCTION KEY SELECT ALERT TYPE, PRESS READ BUTTON TO RETURN TO STAND BY MODE

**SET ALERT TYPE**

FROM STAND-BY MODE ,PRESS FUNCTION KEY THE SCREEN WILL THEN DISPLAY AS BELOW



④ **PRESS FUNCTION BUTTON AGAIN, THE SCREEN WILL THEN DISPLAY AS BELOW**




PRESS FUNTION BUTTON TO SELECT ALERTY TYPE YOU PREFER, PRESS READ BUTTON TO CONFIRM SETTING & RETURN TO STAND-BY MODE

**SETALARM**

PRESS FUNCTION KEY TWO TIMES. THE SCREEN WILL THE DISPLAY AS BELOW



PRESS FUNCTION KEY TWO TIMES. THE SCREEN WILL THE DISPLAY AS BELOW



1:1 SET OF ALARM CLOCK

ON/ -- :ON :ENABLE ALARM CLOCK

-- :DISABLE ALARM CLOCK


00:00 - HOUR & MINUTES SETTING

⑤ PRESS SHIFT KEY TO MOVE CURSOR, PRESS FUNCTION KEY TO ADJUST DATA, PRESS READ KEY TO RETURN TO STAND-BY MODE

**AUTO ON/OFF SETTING**

PRESS FUNCTION KEY UNTIL THE SCREEN DISPLAYS SET AUTOY

PRESS SHIFT KEY, THE SCREEN WILL THEN DISPLAY AS BELOW



ON -00:00 -AUTO ON TIME  
OFF -00:00 -AUTO OFF TIME

PRESS SHIFT KEY TO MOVE CURSOR, PRESS FUNCTION KEY TO CHANGE DATA, PRESS READ KEY TO RETURN TO STAND-BY MODE


NOTE: THIS FEATURE WILL TURN YOUR PAGER ON AND OFF ACCORDING TO THE Them THAT IS SET, MESSAGES WILL NOT BE RECEIVED WHILE THIS FEATURE IS IN USE.

**PAGER OFF SETTING**

⑥ PRESS FUNCTION KEY UNTIL THE SCREEN DISPLAYS PAGE OFF, PRESS SHIFT KEY TO TURN PAGER OFF, PRESS READ BUTTON TO TURN PAGER BACK ON

**SET TIME**

PRESS FUNCTION KEY UNTIL THE SCREEN DISPLAYS SET TIME, PRESS SHIFT KEY THE SCREEN WILL DISPLAY AS BELOW



05 - HOUR  
59 - MINUTES  
12 - DAY OF MONTH  
04 - MONTH  
SU - WEEKDAY

**12/24 HOURS DISPLAY SETTING**

PRESS SHIFT KEY UNDER SET TIME SCREEN UNTIL THE SCREEN DISPLAYS



PRESS FUNCTION BUTTON TO SELECT 24 HOURS OR 12 HOURS DISPLAY SETTING,

⑦ PRESS READ BUTTON TO CONFIRM SETTING & RETURN TO STAND-BY MODE

**READ MESSAGE**

PRESS ANY KEY TO STOP ALERT, PRESS READ KEY TO READ MESSAGE, PRESS READ KEY TO VIEW THE NEXT SCREEN

**LOCK/UNLOCK DELETE INDIVIDUAL MESSAGE**

1. PRESS READ KEY TO SELECT THE MESSAGE YOU WANT TO LOCK, UNLOCK OR DELETE
2. PRESS FUCTION KEY TO LOCK, UNLOCK ,OR DELETE MESSAGE
3. PRESS READ KEY TO CONFIRM YOUR SELECTION

**BACKLIGHT**

TO TURN ON OR THE BACK LIGHT, PRESS SHIFT KEY THE BACK LIGHT WILL AUTOMATICALLY TURN ON/OFF

**DETETE ALL MESSAGE**

PRESS FUNCTION KEY UNTIL THE SCREEN DISPLAY CLEAR ALL. THEN PRESS SHIFT KEY TO DELETE ALL THE UNLOCKED MESSAGES

⑧ **REMINDER**

1. PLEASE CHANGE THE BATTERY RIGHT AWAY WHEN LOW BATTERY ICON IS DISPLAYED, OR YOU MAY MISS MESSAGES
2. DO NOT OPEN THE HOUSING WITHOUT ALLOWANCE